DYNAFLAIR

ROLLING CLOSURE
MOTOR OPERATOR
EMERGENCY RELEASE OPERATION

(MOTOR OPERATOR TOP VIEW)

(RELEASE LEVER)

MOTOR OPERATOR

DISCONNECT CHAIN

(RELEASE PLATE)

(CABLE)

GRILLE/GATE
EMERGENCY OPEN

PULL HANDLE DOWN FULLY

(HOUSING BOX)

TO RETURN TO NORMAL OPERATION
UNLOCK AND RETURN HANDLE TO
FULL UP POSITION

OPERATE MOTOR AT PUSHBUTTON STATION OR
KEYSWITCH FOR 2 SECONDS UP THEN DOWN
UNTIL GATE OR GRILLE OPERATES NORMALLY